




HP Mini 110-3735dx Hard Drive Cage Replacement

This guide will remove the hard drive and the cage it is stored in from your laptop.

Written By: Tyrone Williams



INTRODUCTION

The hard drive cage holds the hard drive and needs to be taken out in order to replace the hard drive. It is also important to remove it because this allows access to other parts of the laptop for replacements.



TOOLS:

- [Phillips #1 Screwdriver](#) (1)
-

Step 1 — Battery



- With the bottom of the HP Mini facing up, slide both switches inward towards each other.

Step 2



- With the left switch still pushed inward, pull the battery towards you to remove it from the computer.


Step 3 — Backcover



- Pull upward from under the back cover via the missing battery area.


i Best to start from one of the corners.

Step 4 — Hard Drive Cage




- Remove the three 5.0 mm screws holding the hard drive cage in place using a Phillips #1 screw driver.

Step 5



- Lift the hard drive cage by pulling the tape upward.
- Start by pulling the tape from the side with the keyboard symbol.

Step 6



- Unplug the cable connecting to the hard drive.

To reassemble your device, follow these instructions in reverse order.

This document was last generated on 2017-06-16 06:14:37 PM.